

SK2XSJ - Full Size Jeep 231 transfer case cable shifter Drill Template

2. Place this top edge flush against transmission tunnel cover.

1. To confirm that this document printed correctly, measure these two lines. Each should be exactly 3 inches long. If they are not, adjust your printer settings to disable scaling and ensure accurate dimensions.

4. Use a center punch to mark these hole locations, then drill 5/16" holes at each mark.

3. Align with bump in floor

3. Align with bump in floor